

- 1. WITHOUT O-RING INSTALLED, INSERT INTENSIFIER SLEEVE INTO HOUSING UNTIL FIRMLY SEATED
- 2. MEASUPE LENGTH X FROM SLEEVE TO RESERVOIR BOTTOM, X MAY BE NEGATIVE.
- 3, REMOVE X+,325 FROM BOTTOM END OF SLEEVE, TOP OF SLEEVE SHOULD BE WITHIN .035 OF SNAP RING BOTTOM WITH RETAINER WASHER IN PLACE.
- 4. INSTALL D-RING AND BACKUP RING. INSERT SLEEVE SLOWLY UNTIL D-RING SEATS IN SNAPRING GROOVE. RAP SHARPLY TO SEAT D-RING & BACKUP. INSTALL NEW PISTON ON SHAFT AND INSERT INTO SLEEVE. INSERT RETAINER WASHER AND NEW 1308-.625 SNAP RING.

MATCOmfg		NOMENCLATURE Installation, intensifier MC-	-5 PART NUI	MBER	SCALE	TOLERANCES (EXCEPT AS NOTED)
2361 S 1560 West WOODS CROSS, UT 84087		MATERIAL	DRÁWING NO. REVÍ		ÍSION A	DO NOT SCALE DRAWING LINEAR .XX = ± .03 .XXX = ± .01
DRAWN BY G. HAPP	FINISH NONE	DATE CT-8-01	CHECKED BY	SHEET 1 OF SHEET SIZE A	1	ANGULAR ±1/2 CONCENTRIC ± .01