

- 1. WITHOUT O-RING INSTALLED, INSERT INTENSIFIER SLEEVE INTO HOUSING UNTIL FIRMLY SEATED TO TEST LENGTH.
- 2. REMOVE MATERIAL FROM <u>BOTTOM END</u> OF SLEEVE SO THAT TOP END (NEAREST O-RING) IS FLUSH WITH END GLAND RELIEF CHAMFER (WITHIN .010). INSTALL O-RING AND INSERT SLEEVE.
- 3, REMOVE OLD PISTON AND INSTALL NEW .500 OD PISTON.

NOTE - SLEEVE MAY BOTTOM ON PEDESTAL FOR MC4-A

MATCOmfg	NOMENCLATURE INSTALLATION, INTENSIFIER MC-4	PART NUMBER	SCALE TOLERANCES (EXCEPT AS NOTED)
2361 S 1560 West WOODS CROSS, UT 84087	MATERIAL DR	RAWING NO. REVI	$\begin{array}{c ccccccccccccccccccccccccccccccccccc$
DRAWN BY G. HAPP NONE	DATE CH	HECKED BY SHEET 1 OF SHEET SIZE A	$\begin{array}{c c} 1 & \text{ANGULAR} \pm 1/2 \\ \hline & \text{CONCENTRIC} \pm .01 \\ \end{array}$