

- 1. WITHOUT O-RING INSTALLED, INSERT INTENSIFIER SLEEVE INTO HOUSING UNTIL FIRMLY SEATED TO TEST LENGTH.
- 2. REMOVE MATERIAL FROM <u>BOTTOM END</u> OF SLEEVE SO THAT TOP END (NEAREST O-RING) IS FLUSH WITH END GLAND RELIEF CHAMFER (WITHIN .010). INSTALL O-RING AND INSERT SLEEVE.
- 3, REMOVE OLD PISTON AND INSTALL NEW .500 OD PISTON.

NOTE - SLEEVE MAY BOTTOM ON PEDESTAL FOR MC4-A

MATCO mfg		NOMENCLATURE INSTALLATION, IN	TENSIFIER MC-	PART NUM	MBER	SCALE	TOLERANCES (EXCEPT AS NOTED)
550W 3615 South Salt Lake City, Utah 84115 USA		I		DRAWING NO. 1-313027		EVISION NC	DO NOT SCALE DRAWING LINEAR .XX = ±.03 .XXX = ±.01
DRAWN BY G. HAPP	FINISH NONE		DATE CT-8-01	CHECKED BY	SHEET 1 OF SHEET SIZE A	1	$0.000 \pm 0.000$ ANGULAR $\pm 1/2$ CONCENTRIC $\pm 0.01$